



MD 200

Steel Mold Release Agent

Description

MD 200 is mold release agent formulated with aliphatic and natural esters and other performance increase additives to release the concrete from molds in easy way.

Fields of Application

Steel mold and plywood mold.

Features and Benefits

- Does not penetrate into the concrete and does not leave any scars.
- Allows to release of concrete easy and smooth from the molds.
- Protects surface smoothness.
- Keeps molds clean.
- Environmental friendly product.

Technical Data

Density	0,80 – 0,90 kg/L
Kinematic Viscosity	13.7 cSt
Flash Point	185°C
Refractive Index (ASTM D 1747)	1,485
HS Code	2710.19.99.00.98

Application Procedure

Preparation of Substrate

The surface must be clean, dry and free from dust, dirt, rust and grease. Molds should be clean.

Application Method

MD 200 is a ready to use material. It is applied on the molds by dipping, spraying, roller or brush. It should be applied as a thin layer.

Floor Systems

MD 200

Steel Mold Release Agent

Consumption

20-30 m² area is greased with 1 kg product depends on mold's surface and type.

Packaging

25 kg plastic drum

Shelf Life

36 months in original, unopened package.

Storage

Store in dry area between +5°C and +35°C. Protect from heat, freezing and direct sunlight.

Cleanup Information

Clean tools and equipment with industrial type solvents immediately after use. Dried material can only be removed mechanically.

Cautions / Limitations

- It may be harmful with skin contact.
- Do not apply in freezing conditions or during precipitation.
- Protect applied materials from rain, freezing, foot traffic and continuous high humidity until completely dry.
- Do not use when air and surface temperatures are below +0°C and above +35°C.

Health and Safety

Warning! Cause eye and skin irritation. If eye or skin contact, get immediate medical attention. If swallowed, do not induce vomiting. Call a physician or poison control center. Never give anything by mouth to an unconscious person.

MD 200

Steel Mold Release Agent

Wash hands thoroughly after handling. Wear protective clothing, gloves, eye and face protection. Do not eat, drink or smoke when using this product. Take off contaminated clothing and wash it before reuse. Dispose of unused, contents, container and other contaminated wastes in accordance with local, state, federal and provincial regulations.

Keep container closed when not in use. Keep out of the reach of children.

Limited Warranty: This product is subject to a written limited warranty which can be obtained free of charge from BAUMERK Company. Please contact with technical service department for further information and support.

Tel: +90 212 438 7 888 Fax: +90 212 438 67 05